



HANGER ARM MOUNTING INSTALLATION

STEP 1



Install post in-ground to desired height. We recommend a minimum of 18" of post burial. Fill hole with roughly 20-25 pounds of "Quickcrete" cement.



STEP 2



Hardware & Tools:

- (6) Threaded Studs
- (6) Acorn Nuts
- (2) 1/2" Machine Screws
- (2) Flat Washers
- 7/16" Wrench
- Allen Wrench

STEP 3



Secure Hanger Arm Brackets to back of sign with the threaded studs and acorn nuts. Be sure to rotate brackets in the direction you wish your sign to hang in relation to the post (left or right). Do not tighten hardware to back of sign completely.

Post Bases & Finials

Install decorative options and secure with provided stainless steel setscrews before attaching sign to post. Be careful not to damage post finish during installation.

STEP 4



Insert hanger arm rods into sign post. Thread 1/2" stainless machine screws using an Allen wrench through post wall.

STEP 5



Adjust sign before tightening bolts.